

Read all instructions BEFORE assembly and USE of product.
KEEP INSTRUCTIONS FOR FUTURE USE.


newton[®]

Travel Crib & Play Yard, Model 5000

**Bassinet Insert, Model 5010
(Optional, Sold Separately)**

Instruction Manual

Scan below
for quick video
assembly guide:



Any questions? Please feel free to contact us at (800)686-3986
or info@newtonbaby.com. We're always happy to help.

MAN5000-20230823

WARNING

Failure to follow these warnings and the instructions could result in serious injury or death. Keep instructions for future use. Assemble product according to the instructions for ANY use mode (Bassinet and Play Yard mode).

Infants can suffocate:

- In gaps between a mattress too small or too thick and product sides
- On soft bedding

NEVER add a mattress, pillow, comforter, or padding.

Use ONLY mattress/pad provided by Newton Baby, Inc.

- The product, including side rails, must be fully erected prior to use.
- Make sure latches are secure.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep, unless otherwise advised by your physician.
- Discontinue use of the product when child is able to climb out or reaches the height of 35 in. (890 mm).
- Always provide the supervision necessary for the continued safety of your child. When used for playing, never leave child unattended.
- Strings can cause strangulation! Never place items with a string around a child's neck such as hood strings or pacifier cords. Never suspend strings over product or attach strings to toys.
- Never place product near a window where cords from blinds or drapes can strangle a child.
- Child can become entrapped and die when improvised netting or covers are placed on top of product. Never add such items to confine child in product.
- When child is able to pull to standing position, remove bumper pads, large toys, and other objects that could serve as steps for climbing out.
- Never use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.
- Never use a water mattress with this product.
- Never use this product if there are any loose or missing fasteners, loose joints, broken parts, or torn mesh/fabric. Check before assembly and periodically during use.
- Contact Newton Baby, Inc. for replacement parts. Never substitute parts.

BASSINET MODE

FALL HAZARD

To help prevent falls, do not use this bassinet insert when the infant begins to push up on hands and knees, can roll over or has reached 15 lbs (6.8 kg), whichever comes first.

ENTRAPMENT HAZARD

Remove bassinet insert once child transitions to the floor mattress of the play yard.

SUFFOCATION HAZARD

Infants have suffocated:

- In gaps between extra padding and side of the bassinet, and
- On soft bedding

Use only the pad provided by Newton Baby, Inc. NEVER add a pillow, comforter, or another mattress for padding.

- If a sheet is used with the pad, use only the one provided by Newton Baby, Inc.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep, unless otherwise advised by your physician.

FALL HAZARD

Prior to use, this bassinet insert:


- Must have its plastic board inserted correctly.
- Must be zippered along its full perimeter into the play yard with the zipper pull tucked under the protective hook and loop fastener flap.
- Pad must lay flat.

Always check that the bassinet insert is securely and fully attached to the play yard before use.


Parts List

Check that all parts listed below are included in your package.
If there are any missing parts, contact Newton Baby for replacements before use.


Play Yard (A)




Part	Part Name	Quantity
A	Play Yard, constructed of:	
B	Vertical Hinges	2
C	Lateral Hinges	2
D	Leg Sockets	4
E	Legs	4
F	Removable Fabric	1
G	Floor Pad, consisting of:	
	Cover:	1
	- Feet	4
	- Strap loops	2
	Core	1
H	Fitted Sheet	1
I	Play Yard Carry Bag	1



Bassinet Insert (Optional, Sold Separately)





Part	Part Name	Quantity
J	Bassinet Insert	1
K	Bassinet Pad, consisting of:	
	Cover:	1
	- Clip	1
	Core	1
L	Fitted Sheet	1
M	Bassinet Insert Carry Bag	1



To Assemble the Play Yard


Step 1

Unlatch strap loops to unroll floor pad and reveal play yard and fitted sheet.




Step 2

Spread open play yard frame until the vertical hinge clicks securely on both long sides.




Step 3

Pull open play yard frame along each short side until the lateral hinge clicks securely.




Step 4

Lay play yard so collapsed legs are accessible on top. Rotate each leg up then slide connected end into corresponding corner leg socket until each joint clicks securely in place.




Step 5

Turn the play yard upright and ensure all latches are locked and the frame secure.




Step 6

Slip on fitted sheet over the floor pad with hook and loop fastener strips exposed on the bottom. Slide out foot through opening in each corner of the fitted sheet.




Step 7

Either drop the pad down through the top opening or enter the side of the play yard (after unzipping the side panel) to insert the pad. Lay floor pad inside play yard ensuring that the hook and loop fasteners attach, and the pad securely fills the floor area. Slide the foot out of each corner opening of the play yard base. Position each leg securely into a foot.



Step 8


For supervised toddler play time, unzip open side panel. To close panel opening, zip closed and secure zipper with clasp.



To Attach Optional Bassinet Insert


Step 1

Unlatch clip to unroll bassinet insert and reveal the bassinet pad and fitted sheet.




Step 2

Latch the bassinet insert zipper to the zipper tape found at the top of the play yard under the protective flap. Attach the bassinet insert securely to the play yard by zipping closed along its full perimeter. Secure the protective flap over the zipper pull.



Step 3

Slip the bassinet fitted sheet over the bassinet pad ensuring all corners are filled properly and the pad lays flat with hook and loop fastener squares exposed on the bottom. With the sheet facing up, lay bassinet pad inside the hanging bassinet insert, ensuring that the hook and loop fasteners attach, and the pad securely fills the bottom area.



⚠ WARNING: FALL HAZARD

Prior to use, this bassinet insert:


- Must have its plastic board inserted correctly.
- Must be zippered along its full perimeter into the play yard with the zipper pull tucked under the protective hook and loop fastener flap.
- Pad must lay flat.

Always check that the bassinet insert is securely and fully attached to the play yard before use.

To Remove and Store Optional Bassinet Insert


Step 4

Lift bassinet pad to detach from the hanging bassinet insert.




Step 5

Open protective flap and unzip bassinet insert to detach from play yard.



Step 6


Place bassinet insert upside down and lay pad on top, then roll closed and fasten clip to secure. Store in bassinet bag.



To Fold and Store the Play Yard


Step 1

Release foot from each leg and insert back inside. Lift floor pad to detach and remove from play yard.




Step 2

Flip play yard upside down. While pushing in leg socket button with one hand, pull straight out the leg from the socket with the other hand. Once released, rotate and fold leg down towards the center. Repeat for all legs.




Step 3

Press lateral hinge on each short edge of the frame and push inwards to fold frame.




Step 4

Press vertical hinge on each long edge of frame and fold frame to bring leg sockets together.



Step 5


Place folded play yard centered on top of the floor pad, then roll closed and fasten strap loops to secure. Store in play yard bag.



Play Yard Fabric Care and Use

Spot cleaning is recommended for most messes. Simply wipe play yard fabric with a damp cloth.

For full cleaning, locate the zipper locking clip under the logo, then press to release. Unzip the zipper along the full top panel of the play yard fabric. Turn the play yard upside down on the floor. While pushing in leg socket button, pull out each leg to release and fold. Collapse each lateral hinge on the short sides of the play yard frame by pressing and pushing each. Then slide each fabric sleeve off each leg before carefully pulling each leg out of the corner openings of the play yard fabric.




Machine wash cold on gentle cycle and tumble dry low. Check the condition of the fabric play yard for any possible damage after each wash. In case of damage, do not use play yard. The play yard frame should have the legs released and the lateral hinges on the short side of the frame folded when reattaching the fabric. Slide each leg through the corner fabric hole then into the corresponding leg sleeve. Then lock each leg into its socket and straighten to lock the lateral hinges to reassemble the play yard frame. Flip play yard upright. Zip closed the zipper along the top fabric panel to fully enclose the metal frame including all hinges. Reattach the zipper locking clip under the logo.

IMPORTANT! Please ensure that all four legs are properly placed through the corner openings and inside the corner sleeves and the top fabric panel is secure around the frame.

Optional Bassinet Insert Removal for Cleaning

Unzip the bassinet insert bottom to remove the plastic board support.



To clean the fabric: Machine wash cold on gentle cycle and tumble dry low. Check the condition of the fabric for any possible damage after each wash. In case of damage, do not use the accessory.

Wipe down the plastic board if soiled.

WARNING! Plastic board must be inserted properly back into the bassinet insert prior to use. The board is notched to only fully insert in one orientation to match the split in the fabric insert. Do not force in the wrong orientation. The slider must be zipped close to secure the board.


Pad Care Instructions

Remove fitted sheet, unzip pad to separate cover and core.


Fitted sheet: Machine wash cold. Tumble dry low.

Pad cover: Zip fully closed prior to wash and dry. For the large floor pad, remove all four feet before laundering. Machine wash cold in gentle cycle with mild detergent. Hang dry. Securely reattach all four feet before use. Ensure zipper is fully closed with the zipper pull securely tucked inside its pocket.


Pad core: Hand rinse cold in shower or tub. Use mild detergent. Shake then air or fan dry. Avoid heat or direct sun.



Removable Foot on Floor Pad



Protective Zipper Pull Pocket



newton®

382 NE 191st Street
Miami, FL 33179

www.newtonbaby.com
info@newtonbaby.com
800-686-3986